

GENERAL SET-UP INSTRUCTIONS

Step 1. Mount the **BRACKET** (part # BKT-WM) as shown.

Step 2. Place the **NOZZLE** (part # PFA-95-AL/BR), head down, on the horizontal ring located on the upper part of the bracket. Ensure the bale handle of the nozzle is lock onto the nozzle hook in a closed position. Secure the nozzle with the straps. Nozzle can be connected to the fire hose permanently in this position if desired.

Step 3. Hang the **EXPANSION TIP** (part # LX-MX-95) on the hook below the nozzle. The **CARRY-ALL BAG** (part # CB) can also be hung on the same hook.

Step 4. Hang the **FOAM BLADDER JACKET** (part # FJ-95) on the horizontal part of the bracket. Ensure the $\frac{3}{4}$ -turn valve is in the closed position and fill the jacket with AFFF.

Step 5. Slip the **UV-RESISTANT COVER** (part # CV-FJ) from the bottom up with the netting facing the deck/floor. Secure the Velcro parts all around including at the top. Secure the foam bladder jacket and the UV-resistant cover with the long straps.